

---

## PRODUCT INFORMATION:

Aslon Rubber sprinttracks are specially developed for intensive use and by applying them on a roll, the floor seams are kept to a minimum. The combination of short fiber and a high density in the mats results in a hard-wearing sport floor.

### YARN:

Material: PE Monofilament  
Yarn type: 9.000/8 Dtex PE. (±5%)  
Weight: 1.104 gr/m<sup>2</sup> (±10%)  
Colour: green, gravel red, blue, white, yellow, black and anthracite

### TUFTING:

Gauge: 3/8  
Height: 12 mm (±10%)  
Stitches: 10 cm<sup>1</sup> ± 30  
1 m<sup>2</sup> ± 31.500

### PRIMARY BACKING:

Backing: Polypropylene  
Weight: ± 135 gr/ m<sup>2</sup>

### BACKING:

Backing: (SBR) Latex compound  
Weight: ± 975 gr/ m<sup>2</sup>

### END PRODUCT:

Total height: 14 mm (±10%)  
Total weight: 2.214 gr/ m<sup>2</sup> (±10%)

### DIMENSIONS:

Width: 2.000 mm and 4.000 mm  
Length: 10.000 mm - 15.000 mm

### INSTALLATION:

The sprint track is delivered on a roll, so we advise to lay out the sprint track 24 hours in advance. Before installation, the surface must be dry, clean, and smooth. Use a leveling compound or filler if necessary to level the floor. It is also possible to place a rubber tile or foam pad underneath the sprint track. Unevenness can affect the sprint track.

Roll up half of the sprint track and attach double-sided tape or 2-component glue to the surface. Place the sprint track on top and press firmly. Then do the same with the other side.

Be careful not to use too much glue, as it can seep through the sprint track. Also, the sprinttrack cannot be removed without damage when glue is used.